



<b>ID</b>	KIJ000100	<b>Creation date</b>	
<b>Platform</b>	S60 2nd Edition	<b>Devices</b>	Nokia 6600
<b>Category</b>		<b>Subcategory</b>	

**Keywords (APIs, classes, methods, functions):**

## Description

VideoControl.setDisplayLocation(x,y) does not work in the Nokia 6600 software version 3.42.1. The method should play the video file in a Canvas at location (x, y), but the video is played at the default location (0, 0) instead.

## Solution

No solutions exist for software version 3.42.1, but this issue has been corrected in software release 4.09.1.