

RDA_WLAN_settings

Most RDA devices have WLAN support and an a proper access point should be pre-defined under connection name "rda". However, if the settings are missing, here are instructions how to define them:

- Connection name: **RDA**
- Data bearer: **WLAN**
- WLAN network name: **RDA** (or select "scan for networks" and select "RDA" from the resulting list)
- Network status: **Public**
- WLAN network mode: **Infrastructure**
- WLAN security mode: **WPA / WPA2**
- WLAN security settings / WPA mode: **Pre-shared key**
- WLAN security settings / Pre-shared key: **forumnokia**

Some devices may have a WLAN wizard, which simplifies the process a bit. For other devices, the right place to define the access point can be found from here:

Tools > settings > connection > Access Points.